

In order for your PSC to function with your PS8 you **MUST update your PS8** and its software and firmware to the latest version available on the website. For update details and instructions on this update process please visit **WWW.ARCAUDIO.COM** or visit our **YouTube** page for step by step instructions of this process.

1. Home button

- Access user menu (from home screen)
- Select feature or finalize adjustment (any screen past home screen)

2. Rotary Encoder

- Volume up and down (from home screen)
- Feature adjustment/attenuation + / - (from selected feature menu)


3. Function 1

- Return to home screen (Hold for 3 seconds)
- Advance back one screen (Press momentarily)
- Access advanced menus (From home screen)
- Manual system on/off (hold for three seconds) – Right handed operation only


4. Function 2

- Mute (From all screens)
- Manual system on/off (hold for three seconds) – Left handed operation only

5. Display



Left Handed Mode



Right Handed Mode